

ATK68 V3 HE

ATK68 V3 HE键盘快捷组合键操作说明

包装内包含:键盘本体，数据线，拔键器，说明书。
使用包装内的数据线，连接键盘与电脑;灯光亮起，即连接成功。

Win锁提示

Fn+Win:短按一次开启，锁定时组合短按一次解除锁定；锁定时，Win键红灯常亮，独立LED灯。

指示灯

1.Caps:红灯，按键下独立LED灯。 2.Winlock:红灯，按键下独立LED灯。

多媒体快捷组合键



+

	Windows	MAC	备注
ESC + Backspace	恢复出厂模式		长按3秒
Q	RGB亮度+		
A	RGB亮度-		
W	RGB效果+		
S	RGB效果-		
E	RGB颜色+		
D	RGB颜色-		
R	RGB速度+		
F	RGB速度-		
N	切换全键无冲/6键无冲		长按3秒
M	切换MAC OS模式	切换WINDOWS模式	长按3秒
Tab	快速开启/关闭所有灯效		
Shift	交换WASD和方向按键		长按3秒
WIN	锁定win模式		
1	F1		
2	F2		
3	F3		
4	F4		
5	F5		
6	F6		
7	F7		
8	F8		
9	F9		
0	F10		
-	F11		
+	F12		

ATK68 V3 HE

ATK68 V3 HE keyboard shortcut key combination operation instructions

Package contains: keyboard body, data cable, key puller, manual.
Use the data cable inside the package to connect the keyboard to the computer;
the light is on, that is, the connection is successful.

WIN LOCK TIPS

Fn+Win:Short press once to turn on, combined short press once to unlock when locked; when locked, the Win key red light is always on, independent LED light.

INDICATOR LIGHT

- 1.Caps:Red light, separate LED under the key.
- 2.Winlock:Red light, separate LED under the key.

MULTIMEDIA SHORTCUT KEYS



+

	Windows	MAC	COMMENT
ESC + Backspace	Restore Factory Mode		Long press 3 seconds
Q	Light Brightness +		
A	Light Brightness -		
W	Light Effect +		
S	Light Effect -		
E	Light Color +		
D	Light Color -		
R	RGB Speed+		
F	RGB Speed-		
N	Toggle full key punchless/6 key punchless		Long press 3 seconds
M	Switch Mac	Switch WIN	Long press 3 seconds
Tab	Light on/off		
Shift	Switch WASD		Long press 3 seconds
WIN	Locked Win Mode		
1	F1		
2	F2		
3	F3		
4	F4		
5	F5		
6	F6		
7	F7		
8	F8		
9	F9		
0	F10		
-	F11		
+	F12		

键盘主要性能输出

- a)额定/Rating: 5V === 500mA
- b)输入方式: USB
- c)按键,全键无冲磁轴键盘，自动识别 N/Key与 6/Key



驱动下载和固件升级

前往ATK官网: WWW.ATK.PRO
可下载最新驱动程序和进行固件升级
体验键盘完整功能

制造商：深圳意义之塔科技有限公司
地址：深圳市宝安区新安街道海旺社区兴华一路(延伸段)19号中兴酒店
(前海HOP国际)1901
网址：WWW.ATK.PRO

合格证 合格证检验:合格

KEYBOARD MAIN PERFORMANCE OUTPUTS

- a)额定/Rating: 5V === 500mA
- b)input type: usb
- c)keys: nkro magnetic switch keyboard, automatic recognition of n/key and 6/key



DRIVER DOWNLOAD AND FIRMWARE UPGRADE

Access to ATK official website:WWW.ATK.PRO
Download the latest drivers and firmware upgrades to
experience the full functionality of the keyboard.

Manufacturer: Shenzhen Yizhita Technology Co., Ltd
Address: Room 1901, Qianhai HOP Int'l, No. 19 Xinghua 1st Rd (Extension), Bao'an District,
Shenzhen, Guangdong, China.
Website: WWW.ATK.PRO

CERTIFICATE OF CONFORMITY

Certificate of Conformity Inspection: Qualified